


Stainless Ball Bushings long version, circular flange







Material

Stainless steel body (440C) with either a resin (POM) or stainless steel (316) retainer.

Stainless steel balls (440C). Supplied with nitrile rubber (NBR) end seals.

Technical Notes

For use with corrosion resistant hardened shafts (see part no. L1772).

Tolerance h6. For part numbers with-1 shaft

tolerance required for these is g6. Temperature range: For resin ball cage -20°C to +80°C.

For stainless ball cage -20°C to +120°C.

Order No.	Ball cage	d_1	d_2	I ₁	وا	l ₃	d_3	d_4	d_5	d_6	Dyn. load C	No. of ball	Static load C ₀	Squareness <i>i</i>	A Weight
		tol. h6	tol. h6	_	_	_	tol.		_	_	N	circuits	N	μm	g
							h4				max.		max.		
L1724.006-RS-1	Resin	6	12	35	5	3,3	28	3,4	6,5	20	320	4	520	15	31
L1724.008-RS	Resin	8	16	45	5	3,3	32	3,4	6,5	24	430	4	780	15	53
L1724.010-RS-1	Resin	10	19	55	6	4,4	40	4,5	8,0	29	580	4	1100	15	105
L1724.012-RS	Resin	12	22	57	6	4,4	42	4,5	8,0	32	650	4	1200	15	100
L1724.016-RS	Resin	16	26	70	6	4,4	46	4,5	8,0	36	1230	5	2350	15	187
L1724.020-RS	Resin	20	32	80	8	5,4	54	5,5	9,5	43	1400	5	2750	17	260
L1724.025-RS	Resin	25	40	112	8	5,4	62	5,5	9,5	51	1560	6	3140	17	515
L1724.006-SS-1	Stainless	6	12	35	5	3,3	28	3,4	6,5	20	320	4	520	15	31
L1724.008-SS	Stainless	8	16	45	5	3,3	32	3,4	6,5	24	430	4	780	15	53
L1724.010-SS-1	Stainless	10	19	55	6	4,4	40	4,5	8,0	29	580	4	1100	15	105
L1724.012-SS	Stainless	12	22	57	6	4,4	42	4,5	8,0	32	650	4	1200	15	100
L1724.016-SS	Stainless	16	26	70	6	4,4	46	4,5	8,0	36	1230	5	2350	15	187
L1724.020-SS	Stainless	20	32	80	8	5,4	54	5,5	9,5	43	1400	5	2750	17	260
L1724.025-SS	Stainless	25	40	112	8	5,4	62	5,5	9,5	51	1560	6	3140	17	515






Applications and tolerances



Linear ball bushings



Applications

- · Computers and peripheral equipment.
- Recording equipment.
- Linear motion systems.
- Multi-axis drilling machine.
- Printing machines.

- Food packaging machines.
- Punching presses.
- Tool grinders.
- · Assembly systems.
- Card selectors.

Interchangeability

Our linear bushing systems are designed to have full interchangeability, with other manufacturers' parts. For shafting see part numbers L1770 to L1785.

High precision retainer

The single body retainer guides 4-6 ball circuits. It precisely guides the balls with a smooth motion.

Tolerance of housing bore

Normal fit is standard, pressed fit is for without clearance.

Туре	Case					
Part no.	Normal fit	Pressed fit				
L1706 to L1733	Н7	K6, J6				
L1706 ⁻¹ to L1733 ⁻¹	Н7	J7				

Rigid outer sleeve

The hardened and precisely ground outer sleeve is made of bearing steel.

L1750 bushing carriages

Consists of light aluminium case and L1706 type linear bushing, so the installation can be finished simply by bolting. Longer life can be obtained by adjusting the orientation of the ball circuits in the linear carriage element against the direction of load.

Tolerance of shaft

Туре	Shaft					
Part no.	Normal fit	Tight fit				
L1706 to L1733	h6	k6				
L1706 ⁻¹ to L1733 ⁻¹	f6, g6	h6				



2

Load rating important information



Basic dynamic load rating C

The basic dynamic load rating is defined as the constant load both in direction and magnitude under which a group of identical linear bushings are individually operated. 90% of the units can travel 50Km without failing due to rolling contact fatigue.

Basic static load rating C_o

If a linear bushing is subject to an excessive load or impact, a permanent deformation occurs between the raceway and the rolling element. The basic static load rating is defined as the static load that gives a prescribed constant contact stress at the centre of the contact area between the rolling element and raceway receiving the maximum load.

Relationships between load ratings and the position of ball circuits

Load ratings of linear bushing are affected by the position of the ball circuits as shown below.

	Orientation of balls						
No of ball rows	Maximum load rating	Minimum load rating					
4	F	F					
	F = 1.41 x C	F = C					
5	F	F					
	F = 1.46 x C	F = C					
6	F	F					
	F = 1.26 x C	F = C					

Load ratings and orientation of balls.





Load rating important information



When designing a linear motion system it is necessary to consider how the application will affect performance. The following examples demonstrate how the position of the load and the centre of gravity can influence product selection. When evaluating your application, review each of the forces acting on your system and determine the product that best suits your needs.

Horizontal application

For uniform speed or when stopped.

$$F_{1z} = \frac{W}{4} + \left(\frac{W}{2} \cdot \frac{d_2}{d_0}\right) - \left(\frac{W}{2} \cdot \frac{d_3}{d_1}\right)$$

$$F_{2z} = \frac{W}{4} - \left(\frac{W}{2} \cdot \frac{d_2}{d_0}\right) - \left(\frac{W}{2} \cdot \frac{d_3}{d_1}\right)$$

$$F_{3z} = \frac{W}{4} - \left(\frac{W}{2} \cdot \frac{d_2}{d_0}\right) + \left(\frac{W}{2} \cdot \frac{d_3}{d_1}\right)$$

$$F_{4z} = \frac{W}{4} + \left(\frac{W}{2} \cdot \frac{d_2}{d_0}\right) + \left(\frac{W}{2} \cdot \frac{d_3}{d_1}\right)$$

$$F_{1z} = \frac{W}{4} + \left(\frac{W}{2} \cdot \frac{d_2}{d_0}\right) + \left(\frac{W}{2} \cdot \frac{d_3}{d_1}\right)$$

$$F_{1z} = \frac{W}{4} + \left(\frac{W}{2} \cdot \frac{d_2}{d_0}\right) + \left(\frac{W}{2} \cdot \frac{d_3}{d_1}\right)$$

Horizontal application

For uniform speed or when stopped.

$$F_{1z} = \frac{W}{4} + \left(\frac{W}{2} \cdot \frac{d_2}{d_0}\right) - \left(\frac{W}{2} \cdot \frac{d_3}{d_1}\right)$$

$$F_{2z} = \frac{W}{4} - \left(\frac{W}{2} \cdot \frac{d_2}{d_0}\right) - \left(\frac{W}{2} \cdot \frac{d_3}{d_1}\right)$$

$$F_{3z} = \frac{W}{4} - \left(\frac{W}{2} \cdot \frac{d_2}{d_0}\right) + \left(\frac{W}{2} \cdot \frac{d_3}{d_1}\right)$$

$$F_{4z} = \frac{W}{4} + \left(\frac{W}{2} \cdot \frac{d_2}{d_0}\right) + \left(\frac{W}{2} \cdot \frac{d_3}{d_1}\right)$$

$$d_3$$

$$F_{1z} F_{4z} = \frac{G_{2z}}{G_{2z}} + \frac{$$




Load rating important information



$$F_{1Y} \sim F_{4Y} = \left(\frac{W}{2} \cdot \frac{d_3}{d_0} \right)$$

$$F_{1z} = F_{4z} = \frac{W}{4} + \left(\frac{W}{2} \cdot \frac{d_2}{d_0}\right)$$

$$F_{2Z} = F_{3Z} = \frac{W}{4} + \left(\frac{W}{2} \cdot \frac{d_2}{d_0}\right)$$



Side mounted application


For uniform speed or when stopped.

$F_{1X} \sim F_{4X} = \left(\frac{W}{2} \cdot \frac{d_2}{d_0} \right)$

$$\mathsf{F}_{1Y} \sim \mathsf{F}_{4Y} = \left(\frac{\mathsf{W}}{2} \cdot \frac{\mathsf{d}_3}{\mathsf{d}_0} \right)$$

$$F_{1X} + F_{4X} \sim F_{2X} + F_{3X}$$

$$F_{1Y} + F_{4Y} \sim F_{2Y} + F_{3Y}$$



Vertical application

For uniform speed or when stopped. On start up/stop the load varies due to inertia in the system.

